



(http://www.xinje.com)

VB5(Basic three-phase type 0.75~3.7KW) Series Inverter Manual

1 Preface


Thanks for using XINJE VB5 series AC Inverters. Please read this manual carefully before you do the operations .This manual describes the procedures for operation and maintenance, including the installation ,parameters setting ,malfunction diagnose and maintenance.

- Please pay attention to the following notes:
- Cut off external power supply before installation and wiring.
- Make sure the power supply of main circuit meets the requirement of inverters well, connect the ground terminal to earth.
- Do not touch the output terminals and avoid any contact with the shell.
- Do not touch the internal circuit and component after turning power off until the indicating light is off of the digital panel on the inverter ,because high voltage may still remain in the inverter.
- Avoid dirt and dust into the internal of inverters because the component built in inverters is sensitive to static electricity.

2 Delivery checking

Using the following when products are delivered: Is there any damage during the delivery? Are the delivery products the ones that were ordered?


Nameplate



If there is a problem please contact with Xinje or an authorized distributor.

Dimension (Unit: mm)

Dimension (Unit: mm)




More details please refer to the following diagram:

Table with 6 columns: Model, W, D1, L, D2, H. Rows include models VB5-40P7, VB5-41P5, VB5-42P2, and VB5-43P7.


3 Wiring

Please pay attention to the main circuit and control circuit when do the wiring on AC inverters and refer to the following diagram(the diagram as below is the standard wiring picture). The control circuit is idle during the operation by the digital panel.

(Note: VB3-4 inverter as a standard 3-phase type connect to power supply with L1,L2,L3 terminals)



Wiring on main circuit



Terminals on control circuit



Terminal description table with 3 columns: Terminal, Name, Description.

Function of jumpers table with 5 columns: No., Function, Setting, Default value.

Function of jumpers

- Make sure the power has been completely cut off for more than 10 minutes when you do the wiring, or else there is risk of electric shock.
- Do separating operation on the power line and the inverter output terminal U, V, W.
- Inverters and motor should be grounding because of leakage current within itself. It is advised to use ordinary copper wire whose diameter is above 3.5mm² and grounding resistance is less than 10Ω.
- All inverters have completely passed the pressure test.
- Contactor and absorption of electromagnetic or other resistance-capacitance capacitor absorbing device can not be installed between the inverter and the motor.
- Please connect inverter to power supply through circuit breaker. In order to protect well in the case of over-current and power off.
- Please use shield twisted wire or cable whose diameter is more than 0.75 mm² when do the wiring on connection between relay and output circuit ,leave one terminal into the space and the other connect to the COM terminal, ensure the wiring line is less than 50m.
- Do the separation on the main circuit and control circuit wiring, if necessary cross the intersection with 90°.

Function of jumpers

Table with 5 columns: No., Function, Setting, Default value. Rows JP2 and JP3.

4 Parameters Setting(Refer to attached table)

5 Specification

Electric Specification

Table with 5 columns: Name VB5 __, OP7, 1P5, 2P2, 3P7. Rows include Output and Input specifications.

Common Characteristics

Table with 3 columns: Environment, Structure, Installation. Rows include application environment, elevation, ambient temperature, humidity, vibration, storage temperature, protection configuration, cooling manner.

General Specification

Main Function table with 3 columns: Modulation mod, Frequency precision, Frequency resolution, Start frequency, Torque boost, V/FFFF curve, Accelerate/Decelerate curve, DC braking, Power consumption braking, Jog, Internal PI, Multi-step speed running, Textile wobble frequency, Auto voltage regulation (AVR), Auto energy saving mode, Auto current limiting.

Digital panel table with 3 columns: Running function, Digital panel, protect function. Rows include Fix-length control, Communication, Command mode, Frequency setting mode, Digital input channel, Analog input channel, Analog output channel, digital output channel, LED Display, connected device, key Lock, Parameter Copy.

6 Alarm diagnoses and solutions

The LED lights indicate alarm code automatically when there is a problem in the inverters, at the same time ,the alarm relay takes into action ,leading the inverter to a stop. Note the running motor coasts to a stop when alarm appears. Causes and solutions can be checked out based on the error code, and device built in inverter records the latest 6 errors, more details please refer to the parameters group P6.

Note: Press Stop/Reset key to reset the alarm elimination the cause of the alarm first.

Alarm code table with 4 columns: Alarm code, Description, Causes, Solutions. Rows E-01 to E-16.

E-17 Error table with 4 columns: E-PROM Read/write error, Error on control, Press STOP/RESET key to reset or contact with a distributor or Xinje.

Parameters setting

- *O*: Means the parameters can be modified during running.
- *X*: Means the parameters don't be allowed to be modified during running
- *R*: Read only, can't be modified

Basic parameters (Group P0)

Table with 6 columns: Code, Name, Range, Unit, Default setting, Note. Rows P0.00 to P0.28.

Frequency setting parameters(Group P1)

Table with 6 columns: Code, Name, Setting range, Unit, Default setting, Note. Rows P1.00 to P1.09.

| | | | | | |
|-------|---------------------------|---|-----|------|---|
| | | Hundred's place of LED: Acc/Dec time selection 0: Acc/Dec time 1 1: Acc/Dec time 2 2: Acc/Dec time 3 3: Acc/Dec time 4 4: Acc/Dec time 5 5: Acc/Dec time 6 6: Acc/Dec time 7 | | | |
| P8.02 | Operating time in stage 1 | 0.1~6000.0 | 0.1 | 10.0 | ○ |
| P8.03 | Stage 2 setup | 000~621 | 1 | 000 | ○ |
| P8.04 | Operating time in stage 1 | 0.1~6000.0 | 0.1 | 10.0 | ○ |
| P8.05 | Stage 2 setup | 000~621 | 1 | 000 | ○ |
| P8.06 | Operating time in stage 1 | 0.1~6000.0 | 0.1 | 10.0 | ○ |
| P8.07 | Stage 2 setup | 000~621 | 1 | 000 | ○ |
| P8.08 | Operating time in stage 1 | 0.1~6000.0 | 0.1 | 10.0 | ○ |
| P8.09 | Stage 2 setup | 000~621 | 1 | 000 | ○ |
| P8.10 | Operating time in stage 1 | 0.1~6000.0 | 0.1 | 10.0 | ○ |
| P8.11 | Stage 2 setup | 000~621 | 1 | 000 | ○ |
| P8.12 | Operating time in stage 1 | 0.1~6000.0 | 0.1 | 10.0 | ○ |
| P8.13 | Stage 2 setup | 000~621 | 1 | 000 | ○ |
| P8.14 | Operating time in stage 1 | 0.1~6000.0 | 0.1 | 10.0 | ○ |

Wobble and measure function parameters (Group 9)

| Group 9: Traverse and measure function parameters (Group 9) | | | | | |
|---|---|--|---------|-----------------|------|
| Code | Name | Setting range | Unit | Default setting | Note |
| P9.00 | Wobble function selection | 0:Disabled 1:Enabled | 1 | 0 | × |
| P9.01 | Wobble operation control mode | 00~11 Unit's place of LED: Start mode 0:Auto mode 1:Manual mode Ten's place of LED: Amplitude control 0:Variable amplitude 1:Fixed amplitude | 1 | 00 | × |
| P9.02 | Pre-wobble frequency | 0.00~500.00Hz | 0.01Hz | 0.00Hz | ○ |
| P9.03 | Waiting time for pre-traverse frequency | 0.0~3600.0s | 0.1s | 0.0s | ○ |
| P9.04 | Wobble operating amplitude | 0.0~50.0% | 0.1% | 0.0% | ○ |
| P9.05 | Jitter frequency | 0.0~50.0% (with reference to P9.04) | 0.1% | 0.0% | ○ |
| P9.06 | Traverse operating cycle | 0.1~999.9s | 0.1s | 10.0s | ○ |
| P9.07 | Rising time of triangle wave | 0.0~98.0% (period of wobble) | 0.1% | 50.0% | ○ |
| P9.08 | Reference length | 0.000~65.535 (km) | 0.001km | 0.000km | ○ |
| P9.09 | Actual length | 0.0~65.535km (can be saved when power off) Saving at power off | 0.001km | 0.000km | ○ |
| P9.10 | Times of length | 0.001~30.000 | 0.001 | 1.000 | ○ |
| P9.11 | correction coefficient of length | 0.001~1.000 | 0.001 | 1.000 | ○ |
| P9.12 | Perimeter of shaft | 0.01~100.00cm | 0.01cm | 10.00cm | ○ |
| P9.13 | Number of pulses per revolution | 1~9999 | 1 | 1 | ○ |

Vector control parameters PA

| Group PA: Vector control parameters | | | | | |
|-------------------------------------|--|--------------------------|--------|-------------------------------|------|
| Code | Name | Setting range | Unit | Default setting | Note |
| PA.00 | Motor auto-tun | 0:No tune 1:auto tune | 1 | 0 | × |
| PA.01 | Rated voltage of motor | 0~400V | 1 | Dependent on inverter's model | × |
| PA.02 | Rated current of motor | 0.01~500.00A | 0.01A | Dependent on inverter's model | × |
| PA.03 | Rated frequency of motor | 1~99Hz | 1Hz | Dependent on inverter's model | × |
| PA.04 | Rated rotated speed of motor | 1~9999 r/min | 1r/min | Dependent on inverter's model | × |
| PA.05 | Polarity of motor | 2~48 | 1 | Dependent on inverter's model | × |
| PA.06 | Stator inductance of motor | 0.1~5000.0mH | 0.1mH | Dependent on inverter's model | × |
| PA.07 | Rotor inductance of motor | 0.1~5000.0mH | 0.1mH | Dependent on inverter's model | × |
| PA.08 | Exciting induction of motor | 0.1~5000.0mH | 0.1mH | Dependent on inverter's model | × |
| PA.09 | Stator resistance of motor | 0.001~50.000Ω | 0.001Ω | Dependent on inverter's model | × |
| PA.10 | Rotor resistance of motor | 0.001~50.000Ω | 0.001Ω | Dependent on inverter's model | × |
| PA.11 | Over current protection coefficient of torque | 0~15 | 1 | 15 | × |
| PA.12 | Percentage adjustment coefficient of speed deviation | 50~120 | 1 | 85 | × |
| PA.13 | Integral adjustment coefficient of speed deviation | 100~500 | 1 | 360 | × |
| PA.14 | Vector torque boost | 100~150 | 1 | 110 | × |
| PA.15 | Reserve | 0 | 0 | 0 | × |
| PA.16 | Reserve | 1~5 | 1 | 4 | × |
| PA.17 | Excitation | 100~150 | 1 | 120 | × |
| PA.18 | Compensating factortor | 0%~150% | 1 | 100% | × |
| PA.19 | Reserve | 0~2 | 1 | 0 | × |

Special Application function parameters PB

| Group PB: Special Application function parameters | | | | | |
|---|--|--|--|--|--|
|---|--|--|--|--|--|

| Code | Name | Setting range | Unit | Default setting | Note |
|-------|---|---|------|-----------------|------|
| PB.00 | Jog frequency source | 0~4 0:P3.06 1:Panel potentiometer 2:P0.02 3:VI 4:CI | | 0 | ○ |
| PB.01 | Selection of forward/reverse dead time | 0, 1 0:Dead time is enabled (Min 0.1S) 1:Dead time can be set to 0 (P0.05=0.0S, P0.20≥0.5Hz is needed) | 1 | 0 | ○ |
| PB.02 | Inverter type selection | 0:G type(normal) 1:P type(wind machine, water pump, power increases 1 level) Note: set as 1, P0.22 must set to 3. | 1 | 0 | × |
| PB.03 | Short the run point before power on, set the run mode | 0:after inverter is power on, run immediately 1:after inverter is power on, cut off the point and connect again to run | 1 | 1 | × |

Factory setting (Group PF)

| Group PF: Factory Setting | | | | | |
|---------------------------|------------------|---|------|-----------------|------|
| Code | Name | Setting range | Unit | Default setting | Note |
| PF.00 | Default password | - | - | - | * |
| PF.01 | User's password | 0:With no password protection 0001 - 9999: password protection | 1 | 0000 | ○ |
| PF.02 | Software version | - | - | - | * |
| PF.03~PF.10 | Reserve | - | - | - | * |

B—Monitor function parameters

| Code | Name | Description | Unit | Default setting | Note |
|-------|--------------------------------|--|--------|-----------------|------|
| b-00 | Output frequency | Present output frequency | 0.01Hz | | * |
| b-01 | Reference frequency | Present reference frequency | 0.01Hz | | * |
| b-02 | Output voltage | Valid value of present output voltage | 1V | | * |
| b-03 | Output current | Valid value of present output current | 0.1A | | * |
| b-04 | Bus voltage | Present DC bus voltage | 1V | | * |
| b-05 | Module temperature | IGBT Temperature of radiator | 10C | | * |
| b-06 | Motor overload speed | Current speed of motor | 1r/min | | * |
| b-07 | Operating time | One continues operating time of inverter | 1hour | | * |
| b-08 | Input/output terminal's status | Digital input/output terminal's status | — | | * |
| b-10 | Analog input CI | Value of analog input CI | 0.01V | | * |
| b-11 | External pulse input | Input value of external pulse range | 1ms | | * |
| b-12 | Inverter rated current | Inverter rated current | 0.1A | | * |
| b-13 | Inverter rated voltage | Inverter rated voltage | 1V | | * |
| b-14 | Display without unit | Display without unit | 1 | | * |
| b-15 | Inverter power class | Inverter power class | - | | * |
| b-16 | Display present counter value | Display present counter value | - | | * |
| b-17 | Reserve | - | - | | * |
| | Reserve | - | - | | * |
| b-40 | Reserve | - | - | | * |

7 Communication parameter

| Name | Address | Function | | |
|---|---------|--|------------------------------------|---------------------|
| Internal parameters setting | GGnnH | GG means parameter group NO., nn means parameters NO. | | |
| Command to inverter (06H) | 2000H | 0001H:Run command (forward) | | |
| | | 0002H:Forward running command | | |
| | | 0003H:Reverse running command | | |
| | | 0004H:Jog command(forward) | | |
| | | 0005H: Jog forward running command | | |
| | | 0006H: Jog reverse running command | | |
| | | 0007H:Dec to a stop | | |
| | | 0008H: Emergency stop command | | |
| | | 0009H: Jog stop command | | |
| | | 000AH: Fault reset command | | |
| | | 2001H | Frequency command setting via port | |
| | | 2100H | Read Inverter's alarm code | |
| Monitoring status (03H) | 2101H | Read Inverter's status | | |
| | | BIT0:Stop indicates. 0:stop; 1:run | | |
| | | BIT1: Under-voltage indication,1:under-voltage;0:normal | | |
| | | BIT2: Forward/reverse indicate,1:Reverse;0: forward | | |
| | | BIT3: Forward/reverse indicate,1: Jog;0:none | | |
| | | BIT4:Close loop control selection,1:close loop;0:none | | |
| | | BIT5: wobble mode running flag,1:traverse;0:none | | |
| | | BIT6:PLC running flag,1:PLC running;0: none | | |
| | | BIT7:Multi-speed running flag of terminals 1: Multi-speed; 0: None | | |
| | | BIT8: Common running flag 1:run as normal;0: none | | |
| | | BIT9: Main frequency from communication interface;1:yes; 0:no | | |
| | | BIT10: Main frequency from analog input. 1:yes;0: no | | |
| BIT11: Running command from communication interface 1: yes; 0: no | | | | |
| BIT12: Password protection for parameters. 1:yes;0: no | | | | |
| | 2102H | Read inverter's reference frequency | | |
| | | 2103H | Read inverter's output frequency | |
| | | 2104H | Read inverter's output current | |
| | | 2105H | Read inverter's bus voltage | |
| | | 2106H | Read inverter's output voltage | |
| | | 2107H | Read motor's speed | |
| | | 2108H | Read module temperature | |
| | | 2109H | Read analog input via VI | |
| | | 210AH | Read analog input via CI | |
| | | 210BH | Read inverter's software version | |
| | | | 210CH | I/O terminal status |
| | | | | Bit0: X1 |
| Bit1: X2 | | | | |
| Bit2: X3 | | | | |
| Bit6: FWD | | | | |
| Bit7: REV | | | | |
| Bit9: relay output | | | | |

| | | |
|-----------------------------------|---|---|
| Read data from function code(03H) | GGnnH (GG: Group No. of function code, nn: function code) | Inverter responses to the data,When use Modbus address, the nn must be turned into hex |
| Write data to function code(06H) | GGnnH (GG: Group No. of function code, nn: function code) | Data be wrote in the inverter, When use Modbus address, the nn must be turned into hex. |

Take the following as examples:

Read function code P1.02
01H, 03H, 01H, 02H, 00H, 01H, CRC1, CRC2
Read the reference frequency of inverter
01H, 03H, 21H, 02H, 00H, 01H, CRC1, CRC2
Write function code P1.02 with value 1
01H, 06H, 01H, 02H, 00H, 01H, CRC1, CRC2
Running command
01H, 06H, 20H, 00H, 00H, 01H, CRC1, CRC2

Definition of fault code

| Fault code | Instruction |
|------------|---|
| 01H | Fault function code, Inverter can not find 03H, 06H, 08H. |
| 02H | Fault data address, Inverter can not find data address |
| 03H | Fault data, data over the limit |

Note: The parameter address must be in hex format, as the function codes of parameters are in decimal system, so make sure turn them to hex format. For example, the Modbus address of function code P2.11 is 020BH.